




1

Tryck på luren för att svara inkommande samtal





Förklaring av skärmen och funktioner

1. Ljusstyrka
2. Volymkontrol
3. 4.3" Färgskärm LED
4. Volym ringsignal (hög - mellan - låg)
5. Knappar

Funktioner knappar.

- Tryck önskad knapp för aktivera dess funktion.



Vänta minst en sekund innan samma knapp trycks igen.



Svarsknapp för att prata.




Öppningsknapp

2

Tryck en gång för att starta kamera,
tryck en gång till för att byta entre´kamera.



Sekretessknapp för att stänga av signal och ljudrr.



1

① EN ► Press the soft-touch audio activation key to answer incoming call. 📞



Monitor description (Pic. 1)

1. Brightness control
2. Loudspeaker volume control
3. 4.3" LED colour screen
4. Call volume adjustment (high - medium - low)
5. Keys

Key description

- Press the desired key to activate the function associated with it.




Wait for approximately 1 sec. before pressing the same key again.



Audio activation key / **Hands-free** mode* enabling

- Press and hold to enable/disable the Hands-free mode.



Lock-release key

1

Key 1 **Actuator** function* (Default)

2

Key 2 **Self-ignition** function* (Default)

- Press and hold to enable/disable the function.

345

Additional keys

Art. 6734W Kit with additional keys sold separately



Privacy* key

Indicator LED description



Steady LED (with call):


audio activated

Steady LED (idle):

Hands-free mode activated

Flashing LED:

incoming call



Flashing LED:

call in progress

1 flash after pressing:

door opening confirmation



4 flashes:

system engaged

Steady LED:

Privacy function enabled

3 flashes (every 5 sec.):

Doctor * function enabled

- To enable/disable the Doctor function press and hold the key programmed for this function*.

* For further information please contact your installer.